

An aerial photograph of a yellow tracked excavator with a long boom, positioned on a dirt surface. The excavator is viewed from above, showing its tracks, engine compartment, and the long boom extending towards the bottom left. The background is a dark blue gradient with white wavy lines.

Trimble Earthworks grade control platform for excavators

Turn overtime into undertime

Get the confidence to deliver projects ahead of schedule.

Ask for the next generation of machine control. From the company that invented machine control.

The **Trimble® Earthworks grade control platform for excavators** is designed to help you do more in less time. Our cutting-edge platform features state-of-the-art software and hardware to give operators of all skill levels the ability to work faster and more productively than ever before.

Also available as a subscription with flexible terms to modernize your equipment with no large upfront cost.



Intuitive software, rugged hardware

The Trimble Earthworks software runs on the Android™ operating system with either the 10-inch (25.4 cm) Trimble TD540 display or the 7-inch (17.8 cm) Trimble TD510 display. Colorful graphics, natural interactions and gestures and self-discovery features make Trimble Earthworks intuitive and easy to learn. Each operator can personalize the interface to match their workflow and a variety of configurable views make it easier to see the right perspective for maximum productivity.

To ensure everyone is operating from the latest design, transfer data files to or from the office wirelessly using Trimble WorksManager software.

Excavator automatics

Take advantage of 3D aftermarket grade control automatics for excavators and tilt-rotator attachments. Excavators can work semi-automatically, allowing operators to create smooth, flat or sloped surfaces more easily. Achieve grade consistently, with high accuracy and in less time by automating excavator operation with Trimble Earthworks.

Augmented reality

Operators can now view 3D models in a real-world environment at a true-life scale, in the context of existing surroundings, using a camera mounted on the outside of the machine. The model is overlaid onto existing ground on the Trimble Earthworks display, giving the operator a better understanding of the work that needs to be done. Visibility of the bucket gives operators better situational awareness of the surroundings.

Augmented reality for excavators enables users to easily understand 3D models, cut/fill information, slope data and other bench and reference points in context, without the need to interpret complex 2D plans or place stakes.


Payload Management integration

Upgrade your Trimble Earthworks system with Payload Management for increased mass haul productivity and efficiency, allowing you to track bucket-by-bucket payload to prevent under- and over-loading. Get real-time insights into progress without additional hardware.




Trimble Earthworks: excavator configurations


Core system




Automatics system



Dual/Single GNSS systems



Universal total station system



Upgraded AS450 Sensor-based Trimble GCS900 grade control systems are only supported in Trimble Earthworks v1.11.X and prior.

FRONTIER PRECISION CIVIL CONSTRUCTION

7125 Old Seward Highway, Suite 100, Anchorage, AK 99518
907.522.1600 | sales@frontierprecision.com
www.frontierprecision.com/solutions/civil-construction

civilconstruction.trimble.com

Trimble Civil Construction

10368 Westmoor Drive
Westminster, CO 80021
USA



© 2021–2025 Trimble Inc. All rights reserved. Trimble, the Globe & Triangle logo, and Connected Site are trademarks of Trimble Inc., registered in the United States and other countries. Android is a trademark of Google LLC. All other trademarks are the property of their respective owners. PN 022482-3681E (11/25)